CENUINE AQUAPRO













CAUTION:

1. IMMEDIATELY AFTER INSTALLATION THE CARTRIDGE WILL DISCHARGE A
VERY SMALL AMOUNT OF CARBON (FINES POWDER). BEFORE THIS CARTRIDGE IS
READY FOR USE, RUN YOUR TAP FOR TWO MINUTIES TO REMOVE FINE POWDER.
2. FOR EACH USE WE RECOMMEND THAT YOUR RUN TAP FOR AT LEAST 60
SECOUNDS PRIOR TO USING WATER, THIS IS ESPECIALLY IMPORTANT IF THE
WATER TAP HAS NOT BEEN USED DAILY.

3. THE CARTRIDGE SHOULD BE CHANGED WHEN CHLORINE RETURN.

PROBLEMS SOLUTION:

| PROBLEMS | SOLUTION METHOD |
|---|---|
| (A) ADAPTOR OR (B) EXTERNAL ADAPTOR NOT FIT TO YOUR FAUCET. | PLEASE CALL YOUR DEALER |
| FILTERED WATER DO NOT FLOW. | 1.CHECK IF THE FAUCET IS OPEN. 2.CHECK IF THE HANDLE OF DIVERTER VALVE IS TURNED HORIZONTALLY. |
| LEAKING IN HOUSING | 1.IF (C) LEAKING, PLEASE CHECK IF O-RING IS IN PROPER POSITION, IF IT'S STILL LEAKING, FOLLOW NEXT DRAWING. 2.IF (D) LEAKING, PLEASE TAKE OFF IT AND WIND TEFLON SEAL ON IT AGAIN. 3.IF (E) LEAKING, SAME AS ABOVE. |
| DREGS? | 1.TAKE OUT O-RING FROM BOWL OF HOUSING, AND CHECK IF THERE ARE ANY DREGS LEFT IN/ON THE GROOVE/O-RING. 2.IF SO,PLEASE REMOVE IT FROM THERE. |
| WATER FLOW BECOME SMALL | 1.CHANGE NEW CARTRIDGE. 2.CHECK IF THE DIVERTER VALVE IS CLOGGED. |
| LEAKING IN THE CONNECTION BETWEEN DIVERTER VALVE AND THREADED FAUCET. LEAKING | 1.CHECK IF THE 2.CHECK IF THE O-RING OF DIVERTER VALVE IS LOST. |
| LEAKING IN THE CONNECTION BETWEEN EXTERNAL ADAPTOR AND UN-THREADED FAUCET. LEAKING | 1.PLEASE CHECK IF THE SPACE BETWEEN THE EXTERNAL ADAPTOR IS TOO LARGE, IF YES, PLEASE PUT THE RUBBERGIOLFINISIDE THE ADAPTOR AND TIGHTEN THE HOSE CLAMP BY SCREWDRIVER. |



FUNCTION:

REMOVAL OF CHLORINE, VOLATILE ORGANIC COMPOUNDS (VOCs),
CHLORINATED HYDROCARBONS, PARTICULATES, AND DISSOLVED ORGIANIC
IMPURITIES FROM WATER, AQUEOUS SOLUTIONS OR SUSPENSIONS AND
MANY ORGANIC SOLVENTS.

FEATURE:

USING CARBON BLOCK REPLACEMENT CARTRIDGE WHICH FIL TERS FLOW IN THE RADIAL (OUTSIDE-TO-INSIDE) DIRECTION, PROVIDING INCREASED DIRT CAPACITY AND LOW PRESSURE DROP.





